

RTA

CABINET STORE

May 20, 2024

Natural Hickory Shaker Kitchen Cabinets Price List



Sink base

Model #	Item	Price
SH-FSB36	Shaker Hickory Farm Sink Base Cabinet - 36" W	\$365.88
SH-SB30	Shaker Hickory Sink Base Cabinet - 30" W x 34.5" H	\$279.78
SH-SB33	Shaker Hickory Sink Base Cabinet - 33" W x 34.5" H	\$296.37
SH-SB36	Shaker Hickory Sink Base Cabinet - 36" W x 34.5" H	\$304.45

Microwave

Model #	Item	Price
SH-MBC30	Shaker Hickory Microwave Base Cabinet - 30" W	\$358.70
SH-MWC3018	Shaker Hickory Microwave Wall Cabinet 18" H x 30" W x 12" D	\$128.24

Filler

Model #	Item	Price
SH-F342	Shaker Hickory Filler - 3" W x 42" H	\$22.87
SH-F396	Shaker Hickory Filler - 3" W x 96" H	\$43.06
SH-F642	Shaker Hickory Filler - 6" W x 42" H	\$45.73
SH-F696	Shaker Hickory Filler - 6" W x 96" H	\$86.08

End panel

Model #	Item	Price
SH-BPLG4896	Shaker Hickory Back Panel (Long Grain) - 48" W x 96" H	\$151.11
SH-DWR3	Shaker Hickory Dish Washer End Panel	\$92.37
SH-OP3353	Shaker Hickory Oven Cabinet Overlay Panel - 33" W x 55" H	\$113.44
SH-TEP3096	Shaker Hickory Tall End Panel	\$206.70

Molding

Model #	Item	Price
SH-BEM8	Shaker Hickory Bottom Edge Molding (Narrow Light Rail)	\$54.70

SH-OCM8	Shaker Hickory Outside Corner Molding	\$20.19
SH-SHOE	Shaker Hickory Shoe Molding	\$16.60
SH-SCM8	Shaker Hickory Shaker Crown Molding	\$53.80
SH-COM8	Shaker Hickory Cove Crown Molding	\$114.34
SH-FBM8	Shaker Hickory Furniture Base Molding	\$75.78

Blind door		
Model #	Item	Price
SH-BB36	Shaker Hickory Blind Base Cabinet for 36" to 39" Space - 30" W	\$370.37
SH-BB42	Shaker Hickory Blind Base Cabinet for 42" to 45" Space - 36" W	\$419.68
SH-BB48	Shaker Hickory Blind Base Cabinet for 48" to 51" Space - 48" W	\$461.83

Pantry		
Model #	Item	Price
SH-P1884	Shaker Hickory Pantry - 18" W x 84" H	\$579.74
SH-P1890	Shaker Hickory Pantry - 18" W x 90" H	\$625.49
SH-P2484	Shaker Hickory Pantry - 24" W x 84" H	\$717.85
SH-P2490	Shaker Hickory Pantry - 24" W x 90" H	\$741.60
SH-P3090	Shaker Hickory Pantry - 30" W x 90" H	\$872.55

Oven		
Model #	Item	Price
SH-OC3390	Shaker Hickory Oven Cabinet - 33" W x 90" H	\$940.25
SH-OCD337	Shaker Hickory Oven Cabinet Drawer	\$243.46

Single door		
Model #	Item	Price
SH-B09	Shaker Hickory Single Door Full Height Base Cabinet - 9" W	\$160.97
SH-B12	Shaker Hickory Single Door Standard Base Cabinet - 12" W	\$221.49
SH-B15	Shaker Hickory Single Door Standard Base Cabinet - 15" W	\$241.68
SH-B18	Shaker Hickory Single Door Standard Base Cabinet - 18" W	\$260.50
SH-B21	Shaker Hickory Single Door Standard Base Cabinet - 21" W	\$281.58
SH-W1230	Shaker Hickory Single Door Wall Cabinet - 12" W x 30" H	\$128.24
SH-W1236	Shaker Hickory Single Door Wall Cabinet - 12" W x 36" H	\$144.37
SH-W1242	Shaker Hickory Single Door Wall Cabinet - 12" W x 42" H	\$172.17
SH-W1530	Shaker Hickory Single Door Wall Cabinet - 15" W x 30" H	\$143.48
SH-W1536	Shaker Hickory Single Door Wall Cabinet - 15" W x 36" H	\$165.45
SH-W1542	Shaker Hickory Single Door Wall Cabinet - 15" W x 42" H	\$195.95
SH-W1830	Shaker Hickory Single Door Wall Cabinet - 18" W x 30" H	\$164.56
SH-W1836	Shaker Hickory Single Door Wall Cabinet - 18" W x 36" H	\$187.42
SH-W1842	Shaker Hickory Single Door Wall Cabinet - 18" W x 42" H	\$223.30
SH-W2130	Shaker Hickory Single Door Wall Cabinet - 21" W x 30" H	\$183.83
SH-W2136	Shaker Hickory Single Door Wall Cabinet - 21" W x 36" H	\$209.40
SH-W2142	Shaker Hickory Single Door Wall Cabinet - 21" W x 42" H	\$248.85
SH-W930	Shaker Hickory Single Door Wall Cabinet - 9" W x 30" H	\$111.64
SH-W936	Shaker Hickory Single Door Wall Cabinet - 9" W x 36" H	\$126.44
SH-W942	Shaker Hickory Single Door Wall Cabinet - 9" W x 42" H	\$150.22

Double door		
Model #	Item	Price
SH-V24-2	Shaker Hickory Double Door Vanity - 24" W x 34.5" H x 21" D	\$214.78

SH-V27	Shaker Hickory Double Door Vanity - 27" W x 34.5" H x 21" D	\$250.65
SH-V30	Shaker Hickory Double Door Vanity - 30" W x 34.5" H x 21" D	\$259.62
SH-W2430-2	Shaker Hickory Double Door Wall Cabinet - 24" W x 30" H	\$218.81
SH-W2436-2	Shaker Hickory Double Door Wall Cabinet - 24" W x 36" H	\$255.13
SH-W2442-2	Shaker Hickory Double Door Wall Cabinet - 24" W x 42" H	\$294.59
SH-W2730	Shaker Hickory Double Door Wall Cabinet - 27" W x 30" H	\$244.37
SH-W2736	Shaker Hickory Double Door Wall Cabinet - 27" W x 36" H	\$276.20
SH-W2742	Shaker Hickory Double Door Wall Cabinet - 27" W x 42" H	\$328.20
SH-W3012	Shaker Hickory Double Door Wall Cabinet - 30" W x 12" H	\$114.34
SH-W3015	Shaker Hickory Double Door Wall Cabinet - 30" W x 15" H	\$141.69
SH-W3018	Shaker Hickory Double Door Wall Cabinet - 30" W x 18" H	\$182.94
SH-W3021	Shaker Hickory Double Door Wall Cabinet - 30" W x 21" H	\$201.32
SH-W3024	Shaker Hickory Double Door Wall Cabinet - 30" W x 24" H	\$224.19
SH-W3030	Shaker Hickory Double Door Wall Cabinet - 30" W x 30" H	\$252.43
SH-W3036	Shaker Hickory Double Door Wall Cabinet - 30" W x 36" H	\$299.07
SH-W3042	Shaker Hickory Double Door Wall Cabinet - 30" W x 42" H	\$355.11
SH-W3312	Shaker Hickory Double Door Wall Cabinet - 33" W x 12" H	\$128.24
SH-W3315	Shaker Hickory Double Door Wall Cabinet - 33" W x 15" H	\$154.70
SH-W3318	Shaker Hickory Double Door Wall Cabinet - 33" W x 18" H	\$195.06
SH-W3324	Shaker Hickory Double Door Wall Cabinet - 33" W x 24" H	\$234.94
SH-W3330	Shaker Hickory Double Door Wall Cabinet - 33" W x 30" H	\$281.58
SH-W3336	Shaker Hickory Double Door Wall Cabinet - 33" W x 36" H	\$321.04
SH-W3342	Shaker Hickory Double Door Wall Cabinet - 33" W x 42" H	\$380.67
SH-W3612	Shaker Hickory Double Door Wall Cabinet - 36" W x 12" H	\$141.69
SH-W3615	Shaker Hickory Double Door Wall Cabinet - 36" W x 15" H	\$158.27
SH-W3618	Shaker Hickory Double Door Wall Cabinet - 36" W x 18" H	\$210.29
SH-W3624	Shaker Hickory Double Door Wall Cabinet - 36" W x 24" H	\$251.54
SH-W3630	Shaker Hickory Double Door Wall Cabinet - 36" W x 30" H	\$291.90
SH-W3636	Shaker Hickory Double Door Wall Cabinet - 36" W x 36" H	\$343.02
SH-W3642	Shaker Hickory Double Door Wall Cabinet - 36" W x 42" H	\$407.13
SH-W3930	Shaker Hickory Double Door Wall Cabinet - 39" W x 30" H	\$330.90
SH-W3936	Shaker Hickory Double Door Wall Cabinet - 39" W x 36" H	\$367.67
SH-W3942	Shaker Hickory Double Door Wall Cabinet - 39" W x 42" H	\$437.18
SH-W4230	Shaker Hickory Double Door Wall Cabinet - 42" W x 30" H	\$343.02
SH-W4236	Shaker Hickory Double Door Wall Cabinet - 42" W x 36" H	\$390.53
SH-W4242	Shaker Hickory Double Door Wall Cabinet - 42" W x 42" H	\$462.72
SH-B24-2	Shaker Hickory Double Door/ Single Drawer Standard Base Cabinet - 24" W	\$311.17
SH-B27	Shaker Hickory Double Door Standard Base Cabinet - 27" W	\$384.27
SH-B30	Shaker Hickory Double Door Standard Base Cabinet - 30" W	\$395.02
SH-B33	Shaker Hickory Double Door Standard Base Cabinet - 33" W	\$429.10
SH-B36	Shaker Hickory Double Door Standard Base Cabinet - 36" W	\$438.06
SH-B39	Shaker Hickory Double Door Standard Base Cabinet - 39" W	\$447.49
SH-B42	Shaker Hickory Double Door Standard Base Cabinet - 42" W	\$460.93

Lazy susan		
Model #	Item	Price
SH-LSB33	Shaker Hickory Lazy Susan Cabinet - 33" W x 24" D	\$635.66
SH-LSB36	Shaker Hickory Lazy Susan Cabinet - 36" W x 24" D	\$668.49

Easy reach		
Model #	Item	Price
SH-ER30	Shaker Hickory Easy Reach Cabinet - 30" W x 24" D	\$121.10

SH-ER33	Shaker Hickory Easy Reach Base Cabinet - 33" W x 24" D	\$434.48
SH-ER36	Shaker Hickory Easy Reach Base Cabinet - 36" W x 24" D	\$467.20

Drawer base		
Model #	Item	Price
SH-DB12-3	Shaker Hickory Drawer Base Cabinet - 12" W	\$334.94
SH-DB15-3	Shaker Hickory Drawer Base Cabinet - 15" W	\$370.37
SH-DB18-3	Shaker Hickory Drawer Base Cabinet - 18" W	\$397.72
SH-DB21-3	Shaker Hickory Drawer Base Cabinet - 21" W	\$425.51
SH-DB24-3	Shaker Hickory Drawer Base Cabinet - 24" W	\$454.65
SH-DB27-3	Shaker Hickory Drawer Base Cabinet - 27" W	\$486.50
SH-DB30-3	Shaker Hickory Drawer Base Cabinet - 30" W	\$518.78
SH-DB33-3	Shaker Hickory Drawer Base Cabinet - 33" W	\$550.61
SH-DB36-3	Shaker Hickory Drawer Base Cabinet - 36" W	\$582.44
SH-VDB12	Shaker Hickory Vanity Drawer Base - 12" W x 34.5" H x 21" D	\$329.11
SH-VDB15	Shaker Hickory Vanity Drawer Base - 15" W x 34.5" H x 21" D	\$356.00
SH-VDB18	Shaker Hickory Vanity Drawer Base - 18" W x 34.5" H x 21" D	\$383.37
SH-VDB24	Shaker Hickory Vanity Drawer Base - 24" W x 34.5" H x 21" D	\$445.23

Other		
Model #	Item	Price
SH-VSBDL30	Shaker Hickory Vanity Combo Cab - Drw Left - 30" W x 21" D	\$388.75
SH-VSBDL36	Shaker Hickory Vanity Combo Cab - Drw Left - 36" W x 21" D	\$459.13
SH-VSBDR30	Shaker Hickory Vanity Combo Cab - Drw Right - 30" W x 21" D	\$388.75
SH-VSBDR36	Shaker Hickory Vanity Combo Cab - Drw Right - 36" W x 21" D	\$459.13
SH-SCRIBE	Shaker Hickory Scribe	\$17.49
SH-SHELF1296	Shaker Hickory Shelf - 96" W x 12" D	\$115.24
SH-SWR3012	Shaker Hickory Stemware Rack	\$38.57
SH-TKS8	Shaker Hickory Toe Kick	\$13.90
SH-TRB18FH	Shaker Hickory Trash Can Base w/ Full Height Door - 18" W	\$488.28
SH-DWR1548	Shaker Hickory Wall Twr w/ 3 Drws - 15" W x 48" H x 14.5" D	\$416.10
SH-DWR1554	Shaker Hickory Wall Twr w/ 3 Drws - 15" W x 54" H x 14.5" D	\$438.97
SH-DWR1560	Shaker Hickory Wall Twr w/ 3 Drws - 15" W x 60" H x 14.5" D	\$475.72
SH-CW2430	Shaker Hickory Corner Wall Cabinet - 24" W x 30" H	\$274.41
SH-CW2436	Shaker Hickory Corner Wall Cabinet - 24" W x 36" H	\$308.04
SH-CW2442	Shaker Hickory Corner Wall Cabinet - 24" W x 42" H	\$390.53
SH-CW2736	Shaker Hickory Corner Wall Cabinet - 27" W x 36" H	\$351.99
SH-CW2742	Shaker Hickory Corner Wall Cabinet - 27" W x 42" H	\$417.88